KINGCLIMA
HENAN KINGCLIMA INDUSTRY CO.,LTD.
ADD: NO 107, NORTH HUAYUAN ROAD, PILOT FREE TRADE ZONE(JINSHUI),ZHENGZHOUHENAN,CHINA
TEL:0371-66379266 / 66379166 Email：info@kingclima.com

PRICE LIST FOR THERMO KING

NO.	NAME	P/N	PICTURE	PRICE(USD)	NOTE
1	Mount Vibration	91-7709			
2	Mount Vibration	91-2619 91-4159			
3	Mount Vibration	99-4820			
4	Mount Vibration	99-3649 93-4060			
5	Mount Vibration	91-4043			
6	Mount Vibration	91-2281			
7	Mount Vibration	91-3908			

8	Bushing Drive Coupler	77-2856			
9	Bushing Drive Coupler	77-2760			
10	Pulley Boss	77-1591			
11	Pulley Water Pump	77-1426			
12	Bushing Pulley Hub	77-2537			
13	Bushing Pulley Hub	77-2537			
14	Pulley	77-2691 SL200E 12954			
15	Pulley	12919			
16	Pulley	77-2397 12967			
17	Idler Pulley	78-1283 77-2936			

18	Idler Pulley	78-1283 77-2936 with bearing			
19	Idler Pulley	78-1284			
20	Idler Pulley	78-1284 with bearing			
21		11-8934			
22		11-8935			
23	Coupler Large 6 Bush（6PIN）	77-2509			
24	Coupler Large 8 Bush（8PIN）	77-2506			
25	Coupler Std 8 Bush	77-2358			
26		6307			
27		6308DU			

28		6207DU			
29		6008DU			
30	Fuel Shut off Solenoid	41-6383			
31	Fuel Shut off Solenoid	42-100			
32	Oil Pressure Switch	41-6865			
33	Oil Pressure Switch	41-7064			
34	Oil Pressure Switch	41-7063			
35		41-5781			
36	Solenoid Run/Stop	44-2823			
37	Solenoid Run/Stop	41-9081 41-9545			

38	Solenoid Run/Stop	44-9181			
39	Fan Motor	41-2281			
40	Regulator Alternator	41-8851 42-2395			
41	Regulator Alternator	41-8851 42-2395			
42	Regulator Voltage	41-1740			
43	Regulator Alternator	44-9143			
44	Brush Holder	41-1739			
45	Water Pump	11-9356			
46	Water Pump	13-506			
47	Water Pump	13-507			

48	Water Pump	13-948			
49	Water Pump	13-2269 13-2270			
50	Water Pump	13-509 13-2572 13-2574 13-0384			
51	Water Pump	11-4576			
52	Drier Filter	61-600			
53	Drier Filter	66-4900			
54	Drier Filter	66-4729			
55	Drier Filter	66-7472			
56	Drier Filter	66-8471 14-00326-03			
57	Drier Filter	61-800			

KINGCLIMA

58	Drier Filter	66-8718 66-8065			
59	Drier Filter	61-3852			
60	Drier Filter	61-3853			
61	Drier Filter	66-8344			
62	Drier Filter	66-7800			
63		67-2706			
64	Drier Filter	66-8548			
65	Drier Filter	66-8546			
66	Drier Filter	66-8546			
67	Drier Filter	61-6630 61-3552			

68		66-8065 14-00326-06			
69	Filter Air	11-7400			
70	Filter Air	11-9300			
71	Filter Air	11-9299			
72	Filter Air	11-9342			
73	Filter Air	11-7382			
74	Filter Air	11-9182			
75	Filter Air	11-6182			
76	Filter Air	11-6228			
77	Filter Air	11-9059			

KINGCLIMA

78	Filter Core Assembly	11-9068			
79	Filter Air	11-9097			
80	Filter Air	11-9098			
81	Filter Air	11-9099			
82	Filter Air	11-9341			
83	Filter Air	11-9321			
84	Filter Air	11-9955			
85	Filter Air	11-9957 11-9965			
86	Filter Air	11-9959			
87	Fuel Filter	11-6285			

88	Fuel Filter	11-7264			
89	Cover Drive Bearing	22-755			
90	Hose Bypass	11-5861			
91	Hose	11-9089			
92	Throttling Valve Kit	60-0298			
93	Shaft Seal	22-777			
94	Shaft Seal	22-778			
95	Shaft Seal	22-778(2)			
96	Shaft Seal	22-1100			
97	Shaft Seal	22-1101 graphite			

98	Shaft Seal	22-1103			
99	Gasket	30-243A			
100	Cylinder Head Gasket	33-2552			
101	O-Ring	33-230			
102	O-Ring	33-1221			
103	O-Ring	33-0408			
104	Oil seal	33-4088 486 front			
105	Oil seal Rear	33-2974 486 back			
106	Rear seal	33-4123			
107	Seal Oil Front	33-2881 D201 front			

108		33-2956			
109		33-1509 353前			
110		33-3819 376前			
111		33-1727 395前			
112		33-2880 D201后			
113		33-2535 C201 后			
114		33-2767			
115		33-3097			
116	Gasket Suction	33-0211			
117	Oil Sump Gasket	33-2514			

118	Manifold Gasket	33-2805			
119	Manifold Gasket	33-2805 with steel wire			
120	Gasket Oil Pump	33-1549 33-5217			
121	Gasket Oil Pump	33-0110			
122	Three-Way Valve Gasket	33-3538			
123	Front Cover Gasket	33-2513			
124	Oil Sump Gasket	33-3797			
125	Oil Sump Gasket	33-2515			
126	Exhaust Manifold Gasket	33-1907			
127	Gasket Kit	482			

KINGCLIMA

128	Gasket Set	30-264 486E			
129	Gasket Set	30-274 486V			
130	Gasket Set	ISUZU			
131	Gasket Set	30-175 C201			
132		30-251 366			
133		30-235 374 3TNE68			
134		30-261 388			
135		30-236 395			
136		3TNV70			
137		3TNM74			

138		3TNV76			
139		3TNV80			
140		33-2932 486			
141		33-3818 3TNV76			
142		3TNM74			
143		33-2937			
144	Gasket Head	33-0792 C201			
145	Gasket Head	33-4209 370			
146	Gasket Head	374			
147	Gasket Head	33-3509 3TNE74 395			

KINGCLIMA

148	Gasket Head	486			
149	Gasket Head	482			
150	Gasket Head	486V/ 33-5056 33-6021			
151	Gasket Head	33-4515 33-4122			
152	Gasket Head	33-1627 D201			
153	Gasket Head	33-2738 3TNE68			
154	Gasket Head	33-1726 366			
155	Valve Cover Gasket	33-2935			
156	Gasket Intake Manifold	33-2936			
157	Head Assembly Cylinder	3TNV70			

158	Head Assembly Cylinder	3TNM72 3TNM74 3TNV74			
159	Head Assembly Cylinder	12-0847 3TNV76 3TNV80			
160	Piston	486V piston			
161		13-0385 71°			
162	Piston Ring	13-0355 486V piston ring			
163	Piston Ring	482 486 piston ring			
164	Piston	486E piston			
165	Piston Ring	11-8949 486E piston ring			
166		11-8916			
167		13-932			

KINGCLIMA

168		13-932			
169	Three Way Valve Repair Kit	60-300			
170	Gasket Kit	30-243			
171	Vibrasorber	66-5964			
172	Vibrasorber	66-2023			
173	Vibrasorber	66-6024			
174	Vibrasorber	66-5717			
175	Vibrasorber	61-4126			
176	Vibrasorber	61-5901			
177	Vibrasorber	61-4127			

178	Vibrasorber	360MM			
179	Vibrasorber	66-5784			
180	Vibrasorber	470MM [SF-3]			
181	Vibrasorber	61-6428			
182	Hose Drain	11-6177			
183	Crankshaft	22-655			
184	Crankshaft	20-0216 (214 crankshaft)			
185	Crankshaft	22-1027			
186	Fuel Pump	11-7500			
187	Fuel Pump	11-9924			

KINGCLIMA

188	Primer Pump	11-8680			
189	Primer Pump	11-5895			
190	Valve Pressure Relief	66-7392			
191	Fuel Pump	41-7059 30-01108-10			
192	Fuel Pump	41-7059 30-01108-10			
193	Fuel Pump	41-7059 30-01108-04 30-01108-10			
194	Injector	11-8715 13-370			
195	Injector	13-0388 486V			
196	Injector	11-8714 482			
197	Tank Receiver	67-1542			

KINGCLIMA

198	Compressor	214 compressor remanufactured			
199	Compressor	X430 (404A system)			
200	Starter Motor	45-1718			
201	Alternator	45-2671 120A			
202	Alternator	45-2257			
203	Alternator	45-2258 (120a)			
204	Alternator	45-2589 45-2695			
205	Alternator	41-2195			
206	Starter Motor	45-1688			
207	Starter Motor	45-2177 45-2753 45-2324			

KINGCLIMA

208	Starter Motor	45-1993			
209	Belt	78-1626			
210	Belt	78-1945			
211	Belt	78-1624			
212	Belt	78-1669			
213	Belt	78-1724			
214	Belt	78-1822 78-1951			
215	Belt	78-1690			
216	Belt	6PK1810			
217	Belt	BX60 17-1525			

218	Belt	BX78 17-1975			
219	Belt	78-1360			
220	Belt	78-0603			
221	Belt	78-0929			
222	Belt	78-1341			
223	Belt	78-0629			
224	Belt	78-1352			
225	Belt	78-1830			
226	Belt	78-1949 78-1486			
227	Belt	78-1273			

228	Belt	78-1544 78-1797			
229	Belt	78-1487 78-1950 78-1271			
230	Belt	78-1987 78-1272			
231	Belt	78-1946 78-1852			
232	Belt	78-1853			
233	Belt	78-1831			
234	Belt	78-1340 78-1968 78-1736			
235	Belt	78-1492			
236	Belt	78-1366			
237	Belt	78-1083			

238	Belt	78-0700			
239	Belt	78-1012			
240	Belt	78-0977			
241	Belt	78-0936			
242	Belt	78-1031			
243	Belt	78-1351			
244	Belt	78-1545			
245	Belt	78-1686			
246	Belt	78-0429			
247	Belt	78-0785			

248	Bearing	6304DU			
249	Bearing	6304N			
250	Thermostat 71ºC	13-0385 71°			
251	Thermostat 82ºC	11-9624 82°			
252	Thermostat	13-0954			
253	Nozzle Injector	11-8978			
254	Cover Thermostat	11-8675			
255		486			
256	Liner Cylinder Sleeve	22-656			
257	Connecting Rod	22-639			

258	Piston	22-850			
259	Valve Plate	22-990			
260	Valve Plate	22-990			
261	Pump Oil	22-1160			
262	Clutch	107-349			
263	Bearing Connecting Rod	22-1003 22-1246			
264		13-0924 486V			
265		13-0920 486V			
266		20305			
267	Temperature Sensor Ungraded	40-0975			

KINGCLIMA

268	Temperature Sensor Ungraded	40-0974			
269	Temperature Sensor	41-8547 40-974(5L)			
270	Temperature Sensor	41-5436			
271	Temperature Sensor	41-3669			
272	Temperature Sensor	41-3847			
273	Sensor RPM	44-6016			
274	Sensor RPM	44-9298			
275	Switch Oil Level Threaded	41-4470			
276	Oil Level Sensor	41-0402			
277	Water Temperature Sensor Switch	41-6539			

278	Sensor Water Temperature	41-6538			
279	Pressure Sensor	42-1309 42-2827			
280	Pressure Sensor	42-1312 41-7962			
281	Pressure Sensor	42-1313			
282	Pressure Sensor	42-1310 42-2284 41-5251			
283	Pressure Sensor	42-1314			
284	Sensor Coolant Temperature	41-7068			
285	Switch Rocker	41-8737			
286		42-1307			
287		41-5047 12V			

288		41-5051 24V			
289		41-5789 12V			
290		41-5791 24V			
291	Solenoid Injection Pump	44-6727			
292		44-8883			
293	Sensor Oil Pressure Switch	44-8883			
294	Tank Coolant Level Sensor Switch	42-2347			
295	Smart Reefer Controller	91-8114 No181			
296	Bearing Damper	99-6565			
297	Isolator Snubber	91-8972			

298	Sensor Temperature	41-8171			
299	Controller	41-8167			
300	Expansion Valve	61-8188 068U4594			
301	Expansion Valve	61-4704 068U4556			
302	Expansion Valve	61-4713 068U3593			
303	Expansion Valve	068U2935			
304		61-7365 068U4574			
305		61-1626 068U2773			
306	Expansion Valve	068Z3403			
307	Expansion Valve	068Z3403			

308	Expansion Valve	068Z3348			
309	Expansion Valve	068Z3209			
310	Fan Shaft	78-1682			
311	Fan Motor	41-4567 (24V)			
312	Fan Motor	41-7568 (12v)			
313	Pulley	77-3159			
314	Pulley Bearing Idler	77-3037			
315	Evaporator Fan Motor	78-1886 78-1554			
316	Fan Evaporator	78-1306			
317	Fan Evaporator	78-1307			

318	Fan Evaporator	78-1306			
319	Fan Evaporator	78-1307			
320	Fan	12" inch fan 12vBlowing			
321	Fan	10" inch fan 12vBlowing			
322	Fan	9" inch fan 12vBlowing			
323	Fan	78-1186 10inch 24V Suction			
324	Fan	78-1188 54-00598-10			
325	Pulley Idler Smooth	77-3186			
326	Pulley Idler Smooth	77-3187 77-3219 77-3217			
327	Valve CPR	61-4527 KVL28			

328	Valve CPR	KVL22			
329	Valve CPR	61-6418 KVL15			
330	Valve CPR	KVL15			
331	Valve CPR	KVL22			
332	Valve CPR	KVL28			
333	Valve CPR	KVL35			
334	Electronic Throttle Valve	61-4525 61-8821			
335	Valve Kit	40-1472 40-1313			
336	Electronic Throttle Valve	61-8820 61-4253			
337	Pump core	X4			

KINGCLIMA

338	Pump core	X4			
339		91-9303			
340	Phase Detector	42-0792			
341	Phase Detector	42-0792			
342	Controller	SR2			
343	Controller	SR3			
344	Controller	SR4			
345	Expansion Tank	12-1028			
346	Tank Coolant	13-1057			
347					

KINGCLIMA

348	Coil radiator	SL200E 12-0582			
349		KV300/RV380			
350	Coil Condenser	67-2818 SV400/600			
351	Coil Condenser	60-0575			
352	Coil radiator	67-2856			
353	Condenser Radiator	67-2854 （60-0575+67-2856）			
354		67-3054			
355		67-2433 T1000 原装			
356	Oil Pump Housing	22-0663			
357	Radiator Cap 7PSI	11-9632			

358	Oil Filler Cap	11-5091			
359	fuel injection pump	101-362 486			
360	Gear Motor Damper	41-3355			
361	Glow Plug	42-0916 370/376			
362		41-9489			
363		41-7370 44-6601 D201			
364	Solenoid starter 12V	DC12V 41-3988			
365	Solenoid starter 24V	DC24V 41-3987			
366	Bearing Set Connecting	22-1005			
367	Smart Reefer Contorller	45-1962			

368		41-8723			
369		66-3852			
370		12-919			
371		12-954			
372	Fuel Injection Spray Nozzle	13-0370			
373	O-Ring	33-3956			
374	Gasket Set	30-262			
375	Filter Drier	61-1620			
376	Belt	78-603			
377		60-156			

378	Sensor Coolant Temperature	44-9588 41-7068			
379	Switch klixon	44-3155			
380	Clutch	10-7349			
381	Bolt	11-8681			
382	Expansion tank	12-0489			
383	Water Pump	12-9356			
384	Gasket Set	30-247			
385	Gasket Set	30-263			
386	O-Ring	33-0230			
387		45-2195			

KINGCLIMA

388	Filter Drier	61-3851			
389	Pulley Nylon	77-3077			
390	Injector Nozzle	11-9046			
391	Throttling Valve Repair Kit	40-1571 40-0997 40-0947			
392	Cylinder Head Cover	22-788 22-789			
393	Gasket Exhaust	33-2314			
394	Hose	13-1016			
395	Fan Motor	DC12V			
396	Fan Motor	DC24V			
397	PCC pressure controller switch marine hydraulic accessories	PSNS-C106			

398	Radiator Cap	11-5406 30-60041-01			
399		66-2020			
400	Freon tank	67-1189			
401	ensioner Belt with Pulley	77-3250 77-3192			
402	Coil Condenser Radiator Kit	67-2436 67-2968			
403		67-2436 67-2968			
404	Pulley Idler	78-1847			
405	Idler Assy Smooth Pulley Complete	77-2900			
406	Idler Pulley Assy Grooved	77-2901			
407	Block Slider	92-6505			

408	Fan Evaporator Motor	78-1374 9 inch			
409	Crankshaft Oil Seal	33-2634 D201后			
410	Control Pannel	45-1959			
411	Pulley Idler Shaft Kit	70-0199			
412	Belt tensioner	77-3189 92-9487 77-3228			
413		22-1027			
414	Idler Pulley	77-3200 With imported bearings			
415	Idler Pulley	77-2708 With imported bearings			
416	Idler Pulley	77-2939 2C42009G03 With imported bearings			
417	Spring - tensioner	78-1887			

418	Lock Washer Star	55-9959			
419	Bearing	77-3124			
420		93-577			
421	Expansion valve	61-1501			
422	Control Premium HMI SR2	45-2385			
423	Inner race - roadside	77-2529			
424	Inner Race - roadside	77-2531			
425	Control Premium HMI SR2	45-2385			
426	Bearing	77-2302			
427	Expansion valve	61-1501			

KINGCLIMA

428	Solenoid	61-6618			
429		61-4667			

KINGCLIMA