

**KINGCLIMA****HENAN KINGCLIMA INDUSTRY CO.,LTD.**ADD: NO 107, NORTH HUAYUAN ROAD, PILOT FREE TRADE
ZONE(JINSHUI),ZHENGZHOUHENAN,CHINA

TEL:0371-66379266 / 66379166


Email: info@kingclima.com

PRICE LIST FOR CARRIER


NO.	NAME	P/N	PICTURE	PRICE(USD)	NOTE
1	Receiver Drier	65-60078-10			
2	Receiver Drier	14-00326-05			
3	Receiver Drier	14-00326-03 66-8471			
4	Receiver Drier	14-00209-00			
5	Receiver Drier	14-00326-04			
6	Receiver Drier	023Z5005			
7	Oil Separator	65-60059-01			

8	Oil Separator	65-60057-01 65-60057-00			
9	Oil Separator	14-60048-00			
10					
11	Receiver Drier	65-66816-00			
12	Receiver Freon Tank	65-60055-06			
13	Oil Separator	R134a.R104a oil separator			
14		65-66813-00 Original			
15		65-66812-01 Original			
16	Fuel Filter	30-00302-00			
17	Fuel Filter	30-60118-00			

18	Fuel Filter	30-60119-00			
19	Fuel Filter	30-00323-00			
20	Fuel Filter	30-00463-00			
21	Fuel Filter	30-00450-00			
22	Fuel Filter	30-00304-00			
23	Fuel Filter	30-01090-05			
24	Fuel Filter	30-01121-00			
25	Air Filter	30-00426-27 30-00426-24			
26	Air Filter	30-00426-20			
27	Air Filter	30-00471-20			

28	Air Filter	30-00430-23			
29	Air Filter	30-60049-20			
30	Air Filter	30-60097-00 30-60097-20			
31	Alternator Regulator	30-01114-52			
32	Regulator Voltage	30-01114-56			
33	Regulator Voltage	30-60050-20			
34	Solenoid	10-01178-00			
35	Solenoid	2848A278			
36	Solenoid Fuel Start Stop	25-15230-01			
37	Solenoid Start Stop	25-38109-06 25-38109-05			

38	Fuel Shutoff Solenoid	25-38773-00			
39	Speed Solenoid	10-60018-00			
40	Motor Evaporator	54-60006-13			
41	Motor Evaporator	54-60006-18			
42	Clutch	50-01171-20 50-01179-00 750(2A157)			
43	Clutch	50-01171-21 850(2A119)			
44	Clutch	50-01171-22 950(2B157)			
45	Clutch	850U 50-01171-24			
46	Clutch Assembly Condenser Fan	50-01173-03 50-00173-03 50-01176-00			
47	Clutch Assembly Condenser Fan	50-01173-03 (After sales)			



48	Fan and Motor	24V 54-00554-01			
49	Fan and Motor	12V 54-00554-00 54-00554-02			
50		54-00668-03			
51		78-1188 54-00598-10			
52	Fuel Pump	41-7059 30-01108-10			
53	Fuel Pump	41-7059 30-01108-10			
54	Fuel Pump	30-01108-04 30-01108-10			
55	Water Pump	25-15425-00			
56	Water Pump	29-70183-00SV			
57	Water Pump	25-34330-00SV 25-15366-00			

58	Water Pump	25-34935-00			
59	Water Pump	25-37581-10			
60	Water Pump	25-15568-00SV			
61	Water Pump	20-11-5436			
62	Water Pump	25-38666-00			
63	Vibrasorber Suction	73-60072-01			
64	Vibrasorber Suction	73-00325-00			
65	Vibrasorber Suction	73-00325-01			
66	Vibrasorber Suction	93-000114-00 570MM			
67	Vibrasorber Suction	430MM [SF-5]			


68	Vibrasorber Suction	360MM			
69	Vibrasorber Suction	73-00201-00 73-00201-02			
70	Vibrasorber Suction	73-00328-10 73-00328-13			
71	Vibrasorber Suction	73-60010-04 73-60010-07			
72	Vibrasorber Suction	73-60035-03			
73	Vibrasorber Suction	73-60013-00			
74	Vibrasorber Suction	73-60010-00 73-60010-06			
75	Vibrasorber Suction	73-60010-02 73-60087-00			
76	Vibrasorber Suction	73-60045-00 73-60076-00 73-60090-00			
77	Vibrasorber Suction	73-60024-02			


78		73-00326-00			
79		73-60024-00			
80	Sensor Combination	12-00500-01SV			
81	Water Temperature Sensor	12-01145-04 12-01145-00 12-00767-00			
82	Temperature Sensor	12-00284-00			
83	Oil Pressure Switch	12-00592-00 12-00592-14			
84	High Pressure Switch	12-00309-04			
85	Pressure Sensor Switch	12-00456-00			
86		12-60032-02			
87		12-60032-03			





88		12-60015-11 原装			
89	Sensor Pressure Transducer	12-00283-00 12-00283-01			
90	Transduce Discharge Sensor Pressure	12-00352-14			
91	Transduce Discharge Sensor Pressure	12-00352-03 12-00352-13			
92		25-15003-00 71°C			
93	Sensor Suction line	22-02973-00 22-02973-14			
94	Sensor Return Air Temperature	22-02973-05 22-02973-16			
95	Shaft Seal	17-44770-00			
96	Shaft Seal	17-57027-00 17-44145-00			
97	Shaft Seal	17-44740-00 05K-1(Steel gasket)			




98	Shaft Seal	17-44785-00			
99	Gasket Valve Plate	17-44007-06			
100	Gasket Valve Plate	17-55002-00			
101	Gasket Valve Plate	17-44746-00			
102	Gasket Valve Plate	17-44747-00			
103	Gasket Valve Plate	17-44022-00			
104	Gasket Valve Plate	17-44124-00			
105	Gasket Valve Plate	17-44123-00			
106	Gasket Valve Plate	17-44126-00			
107	Gasket Front Cover	17-44024-00			

108	Gasket Front Cover	17-44023-00 17-44708-00			
109	Gasket	17-44761-00			
110	Gasket Bearing Case	25-39376-00 V2203			
111		17-44770-00 05G			
112		17-44118-00			
113		17-44119-00			
114		17-44129-00			
115		17-44136-00			
116		17-40104-07			
117	Gasket Set	17-44707-00 05K			


118	Gasket Set	17-44775-00 05G			
119	Gasket Set	17-55020-20 05G 3 PORT			
120	Gasket Service Valve	17-21003-00			
121	Gasket Service Valve	17-10811-05 17-44138-00 05G			
122	Gasket Suction 4 Bolt	17-40005-05			
123	Piston Rings	17-40055-00			
124	Connecting Rod STD	17-40056-02			
125	Piston Std Contoured 37CFM Twin Port	17-44070-00 05G 37CFM			
126	Piston Std Contoured 41CFM Twin Port 活塞环	17-44072-00 05G 41CFM			
127	Piston Contoured Top 41CFM Std	17-44115-01 05K 41CFM			

128	Piston Rings	D1105			
129	Piston Rings	D1105			
130	Transicold Piston Kits	25-39440-00 V2203			
131	Ring Set	25-39442-00 V2203			
132	Bushing Rod	25-38121-00 V2203			
133	Bushing Rod	25-38118-00			
134	Connrod brg Std 134DI	25-39122-00			
135	Suction Valve Reed	17-44111-00			
136	Discharge Valve Reed	17-40086-00			
137	Suction Valve Reed	17-44748-00			

138	Valve Plate	17-44749-00			
139	Head Gasket	25-34503-00			
140	Head Gasket	25-34401-00 D722			
141	Head Gasket	D950			
142	Head Gasket	D1105			
143	Head Gasket	V1505 25-15026-00			
144	Head Gasket	25-39355-00 V2203			
145	Gasket Set	Z482-N			
146	Gasket Set	Z750			
147	Gasket Set	D722 25-34023-00			

148	Gasket Set	D950			
149	Gasket Set	D1105			
150	Gasket Set	V1505			
151	Gasket Set	V2203 25-39537-00			
152	Cylinder Head	D722			
153	Cylinder Head	D950			
154	Cylinder Head	D1105			
155	Cylinder Head	V1505			
156	Cylinder Head	V2203			
157	Cylinder Head	V2403			


158	Sight Glass 3/8	14-01092-06 3/8			
159	Suction Modulation Valve	14-00410-00			
160	Starting Valve	KVL15			
161	Starting Valve	KVL22 14-60000-02			
162	Starting Valve	KVL28 14-00205-01			
163	Starting Valve	KVL35 14-60052-01			
164	Starting Valve	KVL35 14-60052-01			
165	Valve	14-60062-02			
166	Valve	14-00360-10			
167	Thermostat Water	25-39236-01 71°C			

168	Crankshaft	17-44075-00 05G 41CFM			
169	Glow Plug	7103921 D1505 25-15330-00 29-70157-00			
170		KUBOTA V2203			
171	Exhaust Manifold 4.134	V2203 25-39335-00 25-39077-00			
172	Exhaust Manifold	V2203 25-39335-00 SET			
173	Gasket Exhaust Manifold	25-39336-00& 25-39337-00 V2203			
174	Gasket Exhaust Flange	25-39335-00 25-37238-00 for V2203			
175	Bushing	50-00173-04			
176	Brushes Fan Motor	54-60006-30 54-00639-30			
177	Elbow joint	90 1 /2 40-60301-00			

178	Elbow Joint	90 5 /8 40-60301-01			
179	Joint	448-410			
180	Joint	448-400			
181	Alternator	30-01114-06			
182	Alternator	30-01114-07 30-01114-27			
183	Alternator	30-01114-34 30-01114-14			
184	Starter Motor	25-35465-00 29-70158-00			
185	Starter Motor	25-39291-00 25-15520-00 25-39316-00			
186	Starter Motor	25-39587-00			
187	Starter Motor	25-34885-00 29-70050-00			

188	Starter Motor	1G484-63011 25-39476-00			
189	Starter Motor	25-39690-00			
190	Compressor	Valeo TM13			
191	Compressor	Valeo TM15			
192	Compressor	Valeo TM16			
193	Compressor	Valeo TM21			
194	Compressor	Valeo TM31			
195	Muffler	30-60037-00 Z482			
196	Muffler	30-60036-00 D722			
197	Muffler	30-60022-01 D1105			

198	Muffler	30-60052-01 1050 1250			
199	Switch Defrost Air	12-01039-08			
200	Clutch	50-60196-01 50-60196-02			
201	Coupling	48-50005-00			
202	Coupling	48-50005-00			
203	Belt	50-60288-11 alternator belt Supra 550			
204	Belt	50-60032-00 water pump belt (old version)			
205	Belt	50-60329-06 water pump belt (new version) Supra 550 PK			
206	Belt	50-60288-10 alternator belt Supra 750			
207	Belt	50-60296-01 water pump belt (old version) Supra 750			

208	Belt	50-60329-04 water pump belt (new version) Supra 750 PK			
209	Belt	50-60288-02 alternator belt Supra 850			
210	Belt	50-60288-24 50-60288-41 alternator belt Supra 950			
211	Belt	50-60197-06 water pump belt Supra 950			
212	Belt	50-60329-02 water pump belt Supra 950 PK			
213	Belt	50-60288-39 alternator belt Supra1050&1150			
214	Belt	50-00162-25			
215	Belt	50-00178-16			
216	Belt	50-00178-24			
217	Belt	50-00178-19			

218	Belt	50-60411-00			
219	Belt	50-60411-51 50-60411-01 50-01170-00 50-00178-56			
220	Belt	50-60288-13			
221	Belt	50-60289-02			
222	Belt	50-60289-54 50-60289-04			
223	Belt	50-00178-27			
224	Belt	50-60411-05 50-60411-55			
225	Belt	50-60411-06 50-60411-56			
226	Belt	50-60192-06			
227	Belt	50-60288-09			

228	Belt	50-60411-03 50-60411-53			
229	Belt	50-60411-04 50-60411-54			
230	Belt	50-60434-03			
231	Belt	25-15220-00 D722			
232	Belt	50-60329-07			
233	Belt	50-60329-01			
234	Water Pump	25-12425-00			
235	Receiver Drier	65-60078-00			
236		25-37041-00			
237	Oil Seal Crankshaft Front	25-37396-00			

238	Oil Seal Rear	25-37198-00 V2203 后			
239	Cab Command Controller	79-60409-02			
240	Cab Command Controller	79-60482-02			
241		08-60183-00			
242		08-00245-02			
243		79-04067-20 79-04067-21			
244		90-000114-00			
245	Glow Plug Short	25-38150-01 V2203			
246	Crankshaft	17-44725-00 05K 4缸			
247	Radiator Cap	11-5406 30-60041-01			

248	Idler Grooved Shaft	77-2901-02			
249	Condenser Fan Pressure Switch	12-60032-03			
250	Transducer Pressure Suction	12-00352-13 12-00352-14			
251	Solenoid Valve Coil	22-02579-00			
252	Solenoid Valve Coil	22-02579-00			
253	Mobile Climate Control Pressure Switch	12-00299-07			
254	Clutch Repair Kit	50-01165-20 50-50052-00			
255		79-01693-05			
256		3/4			
257	Oil Separator	R134a.R104a油分 2425001			

258		65-60059-02			
259		66-8065 14-00326-06			
260		30-60049-00			
261	Front Bearing	17-44015-00			
262	Seal Oil Front	25-15055-00 V1505 前			
263	Oil Seal Rear Crankshaft	25-15095-00 V1505后			
264	Cab Controller	12-00325-02			
265		14-00443-00			
266	Solenoid	22-69262-00			
267	Solenoid	22-69262-01			

268		22-60590-01			
269		22-60268-01			
270	Thermister Defrost Temp	76-61456-00			
271	Vibration Mount	73-00160-02			
272	Expansion Tank 膨胀水箱	58-60524-03 (with tank lid)			
273	Expansion Tank 膨胀水箱	58-60524-03 (without tank lid)			
274	Expansion Tank 膨胀水箱	58-01432-00 (without tank lid)			
275	Expansion Tank 膨胀水箱	58-01432-00 (with tank lid)			
276	Expansion Tank	58-60524-03			
277		76-00382-00			

278	Idler Tensioner Belt Assy	50-60156-01			
279	Idler Tensioner Belt Assy	50-60005-02			
280	Belt	50-60329-07			
281	Belt	50-60434-00			
282	Check Valve	14-60026-01			
283	Check Valve	14-60026-00			
284	Expansion Valve	14-00247-01			
285	Cab Command Harness	22-60673-03			
286	Spring Clutch	73-00112-00			
287		14-00442-00			

288		22-69271-01			
289		22-69271-00			
290		30-01114-36			
291		30-01114-30 30-01114-10			
292		22-60734-01			
293		14-00393-00 Coil			
294		14-00393-10 Valve			